


Gas BBQ

- Venturi – The burner should burn with a blue flame, if it burns with a yellow flame, the Venturi should be adjusted.



1. Loosen locking screw
2. Adjust Ventura
3. Re-tighten locking screw